

ANTARES - Upgrade

It has been found difficult to connect the ANTARES Dry Glove System in cases where thick base layers/liners are used. The reason is that the liner or seal gets stuck between the latch arms of the Glove Ring and the locking grooves of the ANTARES Oval Stiff Ring. The Support Ring is designed to overcome these issues.



1. Start with pushing the seal so that it gets everted into the drysuit. Place the ANTARES Support Ring as the image shows.

2. Gently press and twist the ANTARES Support Ring into position so that it ends up as image **3** displays.



3. Next step is to fixate the ANTARES Support Ring as close to the ANTARES Oval Stiff Ring as possible without interfering with the seal.

4. Stretch the seal from the inside of the drysuit and at the same time press the ANTARES Support Ring to its final position. No part of the seal shall then be visible between the ANTARES Support Ring and the ANTARES Oval Stiff Ring.



5. Ensure the support flanges aligns with the locking grooves of the ANTARES Oval Stiff Ring as this left image displays.